



## Backer Plate- Proso Millet

Variable Transmission

Cells Per Disc: 60 Cell Milo

Bulk Fill tank Settings: 8-10 (inches of water)

**NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population**

Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
375,000	17.5	345,750	16.1
372,750	17.4	343,500	16.0
370,500	17.3	341,250	15.9
368,250	17.2	339,000	15.8
366,000	17.1	336,750	15.7
363,750	17.0	334,500	15.6
361,500	16.9	332,250	15.5
359,250	16.8	330,000	15.4
357,000	16.7	327,750	15.3
354,750	16.6	325,500	15.2
352,500	16.5	323,250	15.1
350,250	16.3	321,000	15.0
348,000	16.2	318,750	14.9

Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
316,500	14.8	287,250	13.4
314,250	14.7	285,000	13.3
312,000	14.6	282,750	13.2
309,750	14.5	280,500	13.1
307,500	14.4	278,250	13.0
305,250	14.2	276,000	12.9
303,000	14.1	273,750	12.8
300,750	14.0	271,500	12.7
298,500	13.9	269,250	12.6
296,250	13.8	267,000	12.5
294,000	13.7	264,750	12.4
291,750	13.6	262,500	12.3
289,500	13.5	260,250	12.1

**Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.**



Phone: 260-245-5006

Email: [info@davaus.com](mailto:info@davaus.com)

Website: [Davaus.com](http://Davaus.com)