

## **Backer Plate- Radish**

Variable Transmission

Cells Per Disc: 60 Cell Milo

Bulk Fill tank Settings: 8-10 (inches of water)

NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population

Monitor will adjust meter RPM for row spacing				Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
128,250	16.6	99,000	12.8	69,750	9.0	40,500	5.2
126,000	16.3	96,750	12.5	67,500	8.7	38,250	5.0
123,750	16.0	94,500	12.2	65,250	8.5	36,000	4.7
121,500	15.7	92,250	12.0	63,000	8.2	33,750	4.4
119,250	15.5	90,000	11.7	60,750	7.9	31,500	4.1
117,000	15.2	87,750	11.4	58,500	7.6	29,250	3.8
114,750	14.9	85,500	11.1	56,250	7.3	27,000	3.5
112,500	14.6	83,250	10.8	54,000	7.0	24,750	3.2
110,250	14.3	81,000	10.5	51,750	6.7	22,500	2.9
108,000	14.0	78,750	10.2	49,500	6.4	20,250	2.6
105,750	13.7	76,500	9.9	47,250	6.1	18,000	2.3
103,500	13.4	74,250	9.6	45,000	5.8	15,750	2.0
101,250	13.1	72,000	9.3	42,750	5.5	13,500	1.7

Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.

