

JOHN DEERE SMALL CELL DISC- Radish

Variable Transmission

Cells Per Disc: 36

Meter Vacuum Setting: 6-8 (inches of water)

CCS tank settings: 8-10 (inches of water)

NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population

Monitor will adjust meter RPM for row spacing				Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (Ibs/acre)
122,750	11.1	93,500	8.4	64,250	5.8	35,000	3.2
120,500	10.9	91,250	8.2	62,000	5.6	32,750	3.0
118,250	10.7	89,000	8.0	59,750	5.4	30,500	2.8
116,000	10.5	86,750	7.8	57,500	5.2	28,250	2.6
113,750	10.3	84,500	7.6	55,250	5.0	26,000	2.3
111,500	10.1	82,250	7.4	53,000	4.8	23,750	2.1
109,250	9.9	80,000	7.2	50,750	4.6	21,500	1.9
107,000	9.7	77,750	7.0	48,500	4.4	19,250	1.7
104,750	9.5	75,500	6.8	46,250	4.2	17,000	1.5
102,500	9.3	73,250	6.6	44,000	4.0	14,750	1.3
100,250	9.1	71,000	6.4	41,750	3.8	12,500	1.1
98,000	8.9	68,750	6.2	39,500	3.6	10,250	0.9
95,750	8.6	66,500	6.0	37,250	3.4	8,000	0.7

Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.

