

Kinze EdgeVac Small Cell Disc- Radish

Variable Transmission

Cells Per Disc: 60

Meter Vacuum Setting: 10-12 (inches of water)

Bulk Fill tank settings: 8-10 (inches of water)

NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population

Monitor will adjust meter RPM for row spacing				Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
145,000	27.1	111,250	20.8	77,500	14.5	43,750	8.2
142,750	26.7	109,000	20.4	75,250	14.1	41,500	7.8
140,500	26.3	106,750	20.0	73,000	13.7	39,250	7.3
138,250	25.9	104,500	19.5	70,750	13.2	37,000	6.9
136,000	25.4	102,250	19.1	68,500	12.8	34,750	6.5
133,750	25.0	100,000	18.7	66,250	12.4	32,500	6.1
131,500	24.6	97,750	18.3	64,000	12.0	30,250	5.7
129,250	24.2	95,500	17.9	61,750	11.6	28,000	5.2
127,000	23.8	93,250	17.4	59,500	11.1	25,750	4.8
124,750	23.3	91,000	17.0	57,250	10.7	23,500	4.4
122,500	22.9	88,750	16.6	55,000	10.3	21,250	4.0
120,250	22.5	86,500	16.2	52,750	9.9	19,000	3.6
118,000	22.1	84,250	15.8	50,500	9.4	16,750	3.1
115,750	21.7	82,000	15.3	48,250	9.0	14,500	2.7
113,500	21.2	79,750	14.9	46,000	8.6	12,250	2.3

Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.

