

Precision Planting - Barley

Variable Transmission

Meter Vacuum Setting: 6-8 (inches of water)

Bulk Fill tank Settings: 8-10 (inches of water)

Cells Per Disc: 12

NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population

	Monitor will adjust meter RPM for row spacing				
	Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)	
	125,000	145.5	95,750	111.4	
	122,750	142.8	93,500	108.8	
	120,500	140.2	91,250	106.2	
	118,250	137.6	89,000	103.6	
	116,000	135.0	86,750	101.0	
	113,750	132.4	84,500	98.3	
	111,500	129.8	82,250	95.7	
	109,250	127.1	80,000	93.1	
	107,000	124.5	77,750	90.5	
ļ.	104,750	121.9	75,500	87.9	
	102,500	119.3	73,250	85.2	
	100,250	116.7	71,000	82.6	
	98,000	114.0	68,750	80.0	

Monitor will adjust meter RPM for row spacing					
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)		
66,500	77.4	37,250	43.3		
64,250	74.8	35,000	40.7		
62,000	72.2	32,750	38.1		
59,750	69.5	30,500	35.5		
57,500	66.9	28,250	32.9		
55,250	64.3	26,000	30.3		
53,000	61.7	23,750	27.6		
50,750	59.1	21,500	25.0		
48,500	56.4	19,250	22.4		
46,250	53.8	17,000	19.8		
44,000	51.2	14,750	17.2		
41,750	48.6	12,500	14.5		
39,500	46.0	10,250	11.9		

Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.



Phone: 260-245-5006 Email: info@davaus.com Website: Davaus.com